

United's **OXY PRO 718 Professional Multi-Purpose Industrial Descaler** puts the powerful cleaning benefits of oxygen right in your hands. This formula releases added oxygen and hydrogen in a reaction that increases solubility and cleaning power. Safely removes lime, rust, calcium, scale and hard water deposits from hard surfaces.

This OXY PRO formulation:

- Penetrates and dissolves buildup on surfaces to both clean and brighten without harsh scrubbing.
- Safe to use on all metals when used as directed.
- No etching of metals.
- No harsh fumes.
- Hypoallergenic – contains no dyes, no fragrances.

DIRECTIONS FOR USE:

Depending on application, **United 718** can be used full strength or diluted 1 part product to 5 parts water. After application always rinse thoroughly with clean water.

GENERAL PURPOSE CLEANING AND DESCALING:

Dilute with 1 part product to 5 parts of water depending upon soil and scale to be removed. Soak for 3 to 10 minutes. Rinse.

FOR GENERAL USE AS A RUST REMOVER: Dilute with 1 to 5 parts of water depending on density of rust stain to be removed. Soak for 3 to 20 minutes. Rinse.

TO REMOVE SCALE IN DISHWASHING MACHINES:

Dilute between 1 part product to 5 parts water, and full strength. Allow 5 to 10 minutes of contact and then run machine through 2 rinse cycles.

TO REMOVE SCALE AND HARD WATER DEPOSITS FROM ICE MAKERS:

Dilute 1 to 2 parts water. Soak parts and surfaces until clean. Rinse thoroughly with clean water.

TO REMOVE SCALE AND HARD WATER DEPOSITS IN STEAM TABLES:

Apply at 1/2 to full strength. Allow 5 to 10 minutes of contact time. Rinse thoroughly with clean water.

TO REMOVE SCALE AND BUILD-UP FROM POTS, PANS, COFFEE URNS, ETC.:

Soak items to be cleaned in solution of 1 to 5 parts water for 10 to 15 minutes. Rinse thoroughly with clean water.

TO REMOVE HARD WATER DEPOSITS, SCALE AND SOILS FROM DRINKING FOUNTAINS AND HOSPITAL EQUIPMENT:

Vary dilutions based on the type and amount of deposits. Always rinse thoroughly with clean water.

718

OXY PRO

Professional Multi-Purpose Industrial Descaler

UNITED
LABORATORIES

Manufactured and Sold Exclusively by:
UNITED LABORATORIES, INC.
320 37th Avenue • St. Charles, IL 60174
1-800-323-2594 • www.unitedlabsinc.com

DIRECTIONS FOR USE: (continued)

TO CLEAN AND DESCALE WATER METERS AND FILTERS: Do not dilute. Soak until clean. Rinse thoroughly with clean water.

DO NOT use this product on painted surfaces. If unsure of compatibility always test in an inconspicuous area before use.

Food contact surfaces are to be rinsed with potable water after use of this product.

WARNING: Causes serious eye irritation.

Wear eye protection/face protection. Wash face, hands, and any exposed skin thoroughly after handling. **IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. **If eye irritation persists:** Get medical advice/attention.



ADDITIONAL FIRST AID MEASURES:

IF ON SKIN: Wash off immediately with plenty of water for at least 15 minutes.

IF INHALED: Remove to fresh air.

IF SWALLOWED: Clean mouth with water and drink afterwards plenty of water.

CONTAINS (CAS #): Water (7732-18-5), Alcohol C-11 Ethoxylated (68439-46-3), Hydrogen peroxide (7722-84-1)

An SDS for this product is available through United's website. Please read the SDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.

Highly Concentrated and Not Intended for Consumer Household Use

WARNING
KEEP OUT OF REACH OF CHILDREN.



Made in the USA